



Pressure/torque conversion chart Tool model: MXTP-3

PRESSURE		TORQUE		PRESSURE
PSI	FT. LBS	Nm		BAR
1500	464	629		104
1600	496	672		110
1800	559	758		124
2000	622	843		138
2200	685	929		152
2400	748	1.015		165
2600	812	1.100		179
2800	875	1.186		193
3000	938	1.272		207
3200	1001	1.357		220
3400	1064	1.443		234
3600	1128	1.529		248
3800	1191	1.614		262
4000	1254	1.700		276
4200	1317	1.786		290
4400	1380	1.871		303
4600	1444	1.957		317
4800	1507	2.043		331
5000	1570	2.128		345
5200	1633	2.214		358
5400	1696	2.299		372
5600	1759	2.385		386
5800	1822	2.470		400
6000	1885	2.555		414
6200	1948	2.641		427
6400	2011	2.726		441
6600	2074	2.812		455
6800	2137	2.897		468
7000	2200	2.982		482
7200	2262	3.067		496
7400	2324	3.151		510
7600	2387	3.235		524
7800	2449	3.320		538
8000	2511	3.404		552
8200	2572	3.487		565
8400	2634	3.570		579
8600	2695	3.654		593
8800	2757	3.737		607
9000	2818	3.820		620
9200	2878	3.901		634
9400	2938	3.982		648
9600	2997	4.063		662
9800	3057	4.144		676
10000	3117	4.225		690

rev. 3/15/2021